


38 965 000 SAIL FLUSH PLATE



SPARE PARTS

- 1: Screw (Spare part-nr. 6636200M)
- 2: Frame (Spare part-nr. 43207000)
- 3: Top plate with push button (Spare part-nr. 42375000)
- 4: Fixing set (Spare part-nr. 4308500M)*

* Optional accessories